


# 1. PREP VEHICLE FOR INSTALLATION

- Place the vehicle in **PARK**
- **POWER OFF** your '19-20MY F-150 Raptor
- **REMOVE** your Damper Interface Device from the factory packaging

# 2. DISCONNECT FACTORY MODULE

- **IDENTIFY** the factory module located in the drivers footwell of your Ford F-150 Raptor or Expedition.
- **DISCONNECT** the **BLACK** electrical harness connector by simultaneously pressing the connector lock tab towards the outside of vehicle and gently pulling downwards on the connector body.



# 3. INSTALL DAMPER INTERFACE DEVICE

- **CONNECT** the Damper Interface Device to the Vehicle Harness
- **REMOVE** adhesive tape and mount as shown below



# 4. CONFIRM + ENJOY

- **POWER UP** your 2019 F-150 Raptor
- **CONFIRM** Installation by cycling the Factory Drive Modes
- **ENJOY!**

If operation is unsuccessful or there are any Terrain Management System warnings, re-check all connections and key cycle the vehicle. If the problem persists, please contact us at [info@orrsrch.com](mailto:info@orrsrch.com) or check the ORR Forums at [www.orrsrch.com](http://www.orrsrch.com).