

1.

PREP VEHICLE FOR INSTALLATION

- Place the vehicle in **PARK**
- **POWER OFF** your 2019 F-150 Raptor
- **REMOVE** your Damper Interface Device from the factory packaging

2.

DISCONNECT FACTORY MODULE

- **IDENTIFY** the factory module located in the drivers footwell of your Ford F-150 Raptor.
- **DISCONNECT** the **BLACK** electrical harness connector by simultaneously pressing the connector lock tab towards the outside of vehicle and gently pulling downwards on the connector body.



3.

INSTALL DAMPER INTERFACE DEVICE

- **CONNECT** the Damper Interface Device to the Vehicle Harness
- **REMOVE** adhesive tape and mount as shown below



4.

CONFIRM + ENJOY

- **POWER UP** your 2019 F-150 Raptor
- **CONFIRM** Installation by cycling the Factory Drive Modes
- **ENJOY!**

If operation is deemed unsuccessful or there are any Terrain Management System warnings, consult the online ORR factory manual for your Damper Interface Device or contact your local dealer for additional troubleshooting assistance.